

TERADEK BOLT 6 - Częstotliwości według regionu

UWAGA: Po wybraniu innego regionu wymagane jest sparowanie TX i RX

Bandwidth (MHz)	Freq Range		US (FCC)		EU		Canada		Japan		Australia/New Zealand	
	40	20	40	20	40	20	40	20	40	20	40	20
UNII1 (Non DFS)		5160		5160		5160						5160
	5190	5180	5190	5180	5190	5180	5190	5180	5190	5180	5190	5180
		5200		5200		5200		5200		5200		5200
	5230	5220	5230	5220	5230	5220	5230	5220	5230	5220	5230	5220
		5240		5240		5240		5240		5240		5240
	UNII2 (DFS)	5270	5260	5270	5260	5270	5260	5270	5260	5270	5260	5270
5280			5280		5280		5280		5280		5280	
5310		5300	5310	5300	5310	5300	5310	5300	5310	5300	5310	5300
		5320		5320		5320		5320		5320		5320
		5340				5340						5340
5510		5500	5510	5500	5510	5500	5510	5500	5510	5500	5510	5500
		5520		5520		5520		5520		5520		5520
5550		5540	5550	5540	5550	5540	5550	5540	5550	5540	5550	5540
		5560		5560		5560		5560		5560		5560
5590		5580	5590	5580	5590	5580		5580	5590	5580		5580
		5600		5600		5600		5600		5600		
5630		5620	5630	5620	5630	5620			5630	5620		
		5640		5640		5640		5640		5640		
5670/ 5690/ 5710		5660	5670	5660		5660	5670	5660	5670	5660		5660
		5680		5680	5690	5680		5680		5680	5680	
		5700	5710	5700		5700		5700		5700	5690	5700
	5720	5720										
UNII3 (Non DFS)	5755	5745	5750	5740			5755	5745			5755	5745
		5765		5760				5765		5765		
	5795	5785	5790	5780			5795	5785			5795	5785
		5805		5800				5805		5805		
		5825	5830	5820								5825
		5840										

